


DESCRIPCIÓN	CÓDIGO	REFERENCIA	SWR	VOLTS	CONEXIONES
 <p>Temp. de Pre calentamiento <i>Pre-Heating Timer</i> <i>Temp. de Prechauffage</i></p> <p>FORD: Granada 2.5, Scorpio 2.5, Sierra 2.3 OPEL: Ascona 1.6, Astra 1,7D, Kadett 1.6 y 1.7D, Omega 2.3, Senator 2.3, Vectra 1.7D</p>	03002	TPF/6-12	A	12 V	5"
<p>Temp. de Pre-Post calentamiento <i>Pre-Post Heating Timer</i> <i>Temp. de Pre-Post Chauffage</i></p> <p>FORD: Gama 1.8 D</p>	03008	TPPF/6-12	A	12 V	2"
<p>Temp. de Pre-Post calentamiento <i>Pre-Post Heating Timer</i> <i>Temp. de Pre-Post Chauffage</i></p> <p>AUDI, SEAT, VW</p>	03016	TPPSS/7-12	-	12 V	5"

